


## patchS4\_S-0PC-12-1307271 燒錄步驟

操作步驟:

1.


1-1 解壓縮patchS4\_S-0PC-12-1XXXXXX.rar後,進入資料夾

1-1 Unzip patchS4\_S-0PC-12-1XXXXXX.rar to enter the folder.




1-2 複製要燒入的 Patch File .pd2 檔到 patchS4\_S-0PC-12-1XXXXXX.exe 同目錄

1-2 Copy the updated PatchFile.pd2 (F-GPS-4R-XXXXXXX.pd2) file to the same table of contents of patchS4\_S-0PC-1XXXXXX.exe.




### 1-3 進入Setup修改參數

1-3 Go to “setup.cfg” to modify parameters.




### 1-4 依照下面步驟修改設定參數後儲存


1-4 follow below steps to modify parameters and then save them.



1-5 執行patchS4\_S-0PC-XX-XXXXXXX.exe

1-5 Execute patchS4\_S-0PC-XX-XXXXXXX.exe





1-7

